

# Temperature Sensor


The temperature sensor is an accessory that enables up to three simultaneous temperature measurements. Temperature thresholds can be established on the Chariot Smart Drive configuration and it allows you to combine these settings with other conditions to get highly customized event reporting.



010011  
101001  
000100

### highly configurable

Establish thresholds and manage alerts.



### frequent reporting

Regulate temperature monitoring.



### event alerts

Keep well informed with notifications via email or SMS as they occur.

#### KEY FEATURES INCLUDE:

- Report temperature values periodically and on any event generated
- Establish thresholds and create events when the temperature falls below or above these thresholds
- Perform different actions based on those thresholds (for example, activate outputs and send notifications such as email notification and SMS)

